# **Product application**

This thermostat provides electronic control of 24 VAC single-stage heating and cooling systems.

## **System Types**

- Gas, oil, or electric heat with air conditioning
- Warm air, hot water, high-efficiency furnaces, heat pumps, steam, gravity
- Heat only
- · Heat only with fan
- Cool only

# **System Settings**

· Heat, Off, Cool

## **Fan Settings**

· Auto, On

# **Specifications**

### **Temperature Range**

40° to 90°F (4.5° to 32°C)

### **Shipping Temperature**

-20° to 120°F (-28.9° to 48.9°C)

### **Operating Relative Humidity**

• 5% to 90% (non-condensing)


#### **Electrical Ratings**

Voltage: 20–30 VAC

Running current: 0.02–1.0A

# **Installation tips**

Install the thermostat about 5 feet (1.5 m) above the floor in an area with good air circulation at average temperature.



Do not install in locations where the thermostat can be affected by:

- · Drafts or dead spots behind doors and in corners
- · Hot or cold air from ducts
- · Sunlight or radiant heat from appliances
- · Concealed pipes or chimneys
- · Unheated/uncooled areas such as an outside wall behind the thermostat