

**WARNING:** Use of other manufacturer's components will void warranty, safety listing and create a potential safety hazard.

**NOTE:** LOOSEN SCREWS TO ROTATE SHADE IF NECESSARY.  
head snap onto the track.  
cable, press head onto the track until both sides of

**C.** Making sure contacts on head are aligned with

**B.** Snap (12V,20W-MRC11) lamp into socket.

**A.** Space Accent lights no closer than 6" apart.

**ACCENT LIGHT INSTALLATION (USE ONLY WITH AMBIANCE 105° CABLE)**

**WARNING:** Use of other manufacturer's components will void warranty, safety listing and create a potential safety hazard.

**NOTE:** LOOSEN SCREWS TO ROTATE SHADE IF NECESSARY.  
head snap onto the track.  
cable, press head onto the track until both sides of

**C.** Making sure contacts on head are aligned with

**B.** Snap (12V,20W-MRC11) lamp into socket.

**A.** Space Accent lights no closer than 6" apart.

**ACCENT LIGHT INSTALLATION (USE ONLY WITH AMBIANCE 105° CABLE)**

**INSTALLATION AND SAFETY INSTRUCTIONS**

**INSTALLATION AND SAFETY INSTRUCTIONS**

**FOR YOUR SAFETY HC-205**

**FOR YOUR SAFETY HC-205**

**WARNING:** Be sure the electricity to the system you are working on is turned off; either the fuse removed or the circuit breaker set at off

**WARNING:** Be sure the electricity to the system you are working on is turned off; either the fuse removed or the circuit breaker set at off

**WARNING:** RISK OF SHOCK, 24V SYSTEM NOT SUITABLE FOR OUTDOOR USE.

**WARNING:** RISK OF SHOCK, 24V SYSTEM NOT SUITABLE FOR OUTDOOR USE.

**CAUTION:** RISK OF FIRE. USE ONLY 12V LAMPS WITH 12V SYSTEMS. USE OF 12V LAMPS WITH 24V SYSTEM MAY RESULT IN DAMAGE TO SYSTEM AND SURROUNDING AREA.

**CAUTION:** RISK OF FIRE. USE ONLY 12V LAMPS WITH 12V SYSTEMS. USE OF 12V LAMPS WITH 24V SYSTEM MAY RESULT IN DAMAGE TO SYSTEM AND SURROUNDING AREA.

**(USE ONLY WITH AMBIANCE 105° CABLE)**

**(USE ONLY WITH AMBIANCE 105° CABLE)**

**CAUTION-RISK OF FIRE MAX 20 WATT  
TYPE GU4 Bi-Pin MRC11**

**CAUTION-RISK OF FIRE MAX 20 WATT  
TYPE GU4 Bi-Pin MRC11**

**ATTENTION RISQUE D'INCENDIE:** UTILISATION SEULEMENT AVEC LAMPES 12V 12V SYSTEMS. UTILISATION DE LAMPES 12V 24V AVEC SYSTEME PEUT PROVOQUER DES DOMMAGES AU SYSTÈME ET ALENTOURS.

**ATTENTION RISQUE D'INCENDIE:** UTILISATION SEULEMENT AVEC LAMPES 12V 12V SYSTEMS. UTILISATION DE LAMPES 12V 24V AVEC SYSTEME PEUT PROVOQUER DES DOMMAGES AU SYSTÈME ET ALENTOURS.

**(UTILISER UNIQUEMENT AVEC LE CÂBLE 105° DE L'AMBIANCE)**

**(UTILISER UNIQUEMENT AVEC LE CÂBLE 105° DE L'AMBIANCE)**

**ATTENTION-RISQUE D'INCENDIE MAX 20 WATT  
TYPE GU4 Bi-Pin MRC11**

**ATTENTION-RISQUE D'INCENDIE MAX 20 WATT  
TYPE GU4 Bi-Pin MRC11**

**IMPORTANT SAFETY INSTRUCTIONS**

**IMPORTANT SAFETY INSTRUCTIONS**

1. Bulb gets hot quickly! Turn off and allow to cool to replace bulb.
2. Do not remain in light if skin feels warm.
3. Do not look directly at lighted bulb.
4. Minimum distance from combustible materials. To front of lamp is 4", from lamp rim is 3/4" (see diagram). Allow clearance not only for shelf but also for items that might be displayed on the shelf.

1. Bulb gets hot quickly! Turn off and allow to cool to replace bulb.
2. Do not remain in light if skin feels warm.
3. Do not look directly at lighted bulb.
4. Minimum distance from combustible materials. To front of lamp is 4", from lamp rim is 3/4" (see diagram). Allow clearance not only for shelf but also for items that might be displayed on the shelf.